


# **INSTRUCTIONS**

## YOUR MINI FRIDGE WILL OPERATE FROM EITHER 12 VOLT D.C. OR A.C. POWER ADAPTOR







Your MINI FRIDGE is supplied with a power cord to fit either a car, boat, van or RV cigarette lighter socket or our optional A.C. adaptor for home use. Never attempt to connect directly to A.C. without this adaptor.

Just plug into either supply and plug the other end of the cord into your MINI FRIDGE

Never cut cord or reverse wires. This would damage your MINI FRIDGE (See Inside for other connection details)





Plug your MINI FRIDGE I into power source and switch to hot or cold as desired. Light should illuminate as shown. If no lights are on, no power is coming through - check connections.

If low battery light is on, your battery needs charging or connections are bad.

If wrong light is on, i.e. hot, when switched to cold, unplug it IMMEDIATELY. This means the power is reversed and it will damage your MINI FRIDGE. Check that the connections in your vehicle are correct and that the system is 12 volt D.C. negative ground and not positive ground.

#### **TECHNICAL SPECIFICATIONS**

#### **Exterior Dimensions** Interior Dimensions

16 inches 41 cm 111/2 inches 29 cm Length 28 cm 8 inches 8 inches s 29 cm 8 inc 0.4 cu. ft. 10.5 litres 10 lbs. 4.5 kg. 11% inches Width 20 cm Capacity Weight

Voltage: 12 volts D.C. 10% residual A.C. ripple maximum allowable. Current: 3.8 amps nominal +/- 10% for cooling. Heating will be less.

Maximum heat pump capacity: 120 B.T.U.

Temperature Control: thermistors, linear I.C., low power transistor, diodes

Indicators: Light emitting diodes for hot, cold and low battery. Accessories provided: one 6ft. (2 metre) power cord.

Optional extra: 12 volt D.C. adaptor

Your MINI FRIDGE power drain is approximately equal to one car headlight

Battery consumption: Although your MINI FRIDGE draws approximately 4.0 amps and the average car battery is rated at 60 amp/hours, it is a good idea not to operate your MINI FRIDGE for more than 3 to 5 hours without running your car for a short time to ensure your battery is in good condition. If the battery runs down in this time then you may have a faulty battery or car generator. This is quite common so have them checked to avoid any inconvenience. Of course you may use your MINI FRIDGE continuously while the car is running since the generator provides more than enough power.

### The Ideal A.C. Power Adaptor specially designed for your



#### FRIDGE MINI AND FOOD WARMER

Now you can take your MINI FRIDGE with you and use it in

Motel rooms, Patios, Rec. Rooms, Beside your pool, Cottages, Locker rooms, Construction sites, As a bar fridge ...

> Anywhere there's house current available.

THE A.C. POWER ADAPTOR HAS A CIGARETTE LIGHTER RECEPTACLE SIMILAR TO YOUR CAR, VAN OR R.V.

SO EASY TO OPERATE! SIMPLY PLUG THE POWER CORD THAT COMES WITH YOUR UNIT, FROM YOUR MINI FRIDGE CONTROL PANEL INTO THE ADAPTOR'S LIGHTER RECEPTACLE, THEN PLUG THE POWER ADAPTOR INTO THE A.C. OUTLET.



A PRODUCT OF

**ELECTRONICS**